


**P10**

***Tanaka***

**PM-55**

**Serial No.**


**P10-01 PM-55 CYLINDER/PISTON/CRANK SHAFT**



REF. NUMBER	PARTS NUMBER	QTY	SERIAL NUMBER
006	157-11666-90	1	
007	255-04200-20	1	
008	018-06540-21	1	
011	001-0422U-90	1	
012	994-61050-184	4	
014	017-04220-21	1	
015	041-04090-21	2	
016	030-0422U-90	1	
017	037-04090-20	1	
018	039-01000-20	2	
020	036-04090-20	2	
021	046-04220-80	1	
022	999-62101-480	1	
031	068-02000-20	1	

# P10-02


## PM-55 CRANK CASE



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
019	788-0162V-20	1	
020	993-55050-000	1	
023	991-11100-013	1	
024	790-0162V-20	1	
025	798-04220-90	1	
026	072-04220-91	1	
027	090-04200-21	1	
028	999-66152-500	2	
029	999-61620-200	2	
030	070-02401-20	2	
032	071-02007-20	V	
032	071-02007-21	V	
032	071-02007-22	V	
032	071-02007-23	V	
032	071-02007-24	V	
036	994-14060-451	2	
038	994-14060-301	2	
040	191-04276-90	1	
046	991-01060-013	1	
047	894-01401-20	1	
051	155-20537-80	1	
052	992-00100-011	1	
054	991-11100-011	1	
055	167-20537-80	1	
056	994-14050-181	2	
058	992-00050-011	2	
063	198-05015-80	1	
066	112-04230-21	1	
067	994-14060-202	4	
068	203-10000-20	1	
069	203-06000-20	1	

**P10-03**


**PM-55 ENGINE-1**




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
027	655-04200-20	2	
031	403-04220-21	1	
032	404-0422U-90	1	
033	402-01740-20	1	
045	455-0422U-90	1	
049	994-16050-241	2	
051	495-04200-20	1	
052	700-02504-09	2	
053	991-11100-011	1	
054	992-20100-010	1	
055	422-25030-80	1	
063	223-01251-90	1	
064	680-00731-20	1	
065	675-01630-90	1	
066	591-04220-21	1	
068	534-32710-20	1	
070	595-0423Q-91	1	
076	603-04201-20	1	
077	652-04201-20	1	
078	994-15050-162	2	
096	626-32550-20	1	

**P10-04**


**PM-55 ENGINE-2**



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	738-04220-20	1	
002	994-15050-122	1	
003	994-61050-124	1	
004	992-01050-061	1	
005	990-53060-653	2	
006	992-01060-011	2	
007	704-0423Z-90	1	
009	751-04200-20	1	
010	721-0423Z-90	1	
011	994-14040-081	2	
014	737-04230-20	1	
016	133-04230-20	1	
023	994-15050-182	2	
024	994-15050-252	2	
025	653-04200-20	1	
026	655-06100-20	2	
081	359-10112-20	2	
082	290-04270-80	2	
083	342-04270-20	1	
084	992-04100-030	2	
085	357-0136U-20	2	

**P10-05****PM-55 RECOIL STARTER**


REF. NUMBER	PARTS NUMBER	QTY	SERIAL NUMBER
000	762-04220-90	1	
001	772-04220-80	1	
002	769-04220-20	1	
003	779-04220-20	1	
009	783-04220-20	1	
012	835-04220-20	1	
014	785-04220-20	1	
017	839-04220-20	1	

**P10-06****PM-55 AIR CLEANER**

REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
036	423-04270-20	1	
037	659-00801-20	2	
038	476-04050-20	1	
039	446-0652N-20	1	
041	424-04270-90	1	
042	450-04072-20	1	
043	994-14050-601	2	


**P10-07**

**PM-55 CARBURETOR**



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	514-25001-20	1	
002	575-25012-20	1	
003	577-25012-20	1	
004	576-25012-20	1	
005	578-25007-20	1	
017	463-25012-20	1	
018	462-25006-20	1	
019	623-25054-20	2	
020	461-25032-20	1	
021	460-25032-20	1	
022	603-25012-20	1	
023	477-25051-20	1	
024	473-25012-20	1	
025	605-25001-20	1	
026	546-25001-20	1	
027	475-25032-20	1	
028	474-25032-80	1	
029	454-25032-80	1	
030	476-25032-20	1	
031	548-25016-20	4	




**P10-08****PM-55 CLUTCH CASE**

REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	289-04205-80	1	
003	999-61620-202	2	
004	993-50015-002	1	
005	347-04201-20	1	
006	994-14050-161	4	
009	599-04201-81	1	
010	331-04201-20	1	
011	994-61050-124	4	
013	990-51050-103	1	
014	282-04201-20	1	
015	990-53060-453	1	
016	992-10060-062	1	
017	992-01060-061	1	
018	991-91060-061	1	

**P10-09**


**PM-55 OPERATION PIPE**



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	343-37121-20	1	
002	341-37100-80	1	
003	347-37100-90	5	
042	335-37121-20	1	
043	334-37121-20	2	
044	994-62050-304	2	
046	315-37304-20	1	
061	502-37415-21	1	
063	165-37590-20	1	
064	994-61050-224	4	
066	506-37121-20	1	
067	507-37121-20	1	
069	508-33411-20	1	
071	994-81060-254	2	
074	460-33111-20	1	
084	164-13016-00	1	
091	746-37455-91	1	
092	501-37169-20	1	
095	870-37168-90	1	
098	253-38400-20	1	
100	832-38400-20	1	
101	880-38401-20	1	
103	322-38400-20	1	
106	993-46040-202	2	
107	994-31050-303	1	
108	991-01050-043	1	
110	156-37168-80	1	
120	887-37168-80	1	
125	885-37168-80	1	

**P10-10**

**PM-55 GEAR CASE**



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	300-37861-90	1	
002	994-61050-254	2	
004	993-51028-002	1	
005	993-50012-002	1	
006	999-61600-102	1	
007	999-61600-100	1	
009	300-33392-21	1	
011	994-61050-124	1	
012	994-23080-100	1	
013	999-61600-000	1	
015	304-37850-20	1	
016	999-61620-303	1	
017	993-51040-002	1	
018	310-37100-21	1	
019	311-37861-20	1	
020	307-37100-81	1	
021	994-16050-162	3	
022	313-38100-20	1	
023	324-37110-20	2	
026	994-81060-254	2	
028	442-37121-20	1	
029	441-37130-20	1	
030	445-37380-20	1	
031	447-37380-20	1	
032	797-37380-21	1	
034	994-14050-121	1	
035	301-37100-00	1	
036	991-01050-011	1	
045	327-37180-90	1	
050	308-37861-20	1	