


B11

***Tanaka***

**SUM-500/500N**


Serial No. - S001000

**B11-01****SUM-500/500N CYLINDER / PISTON / CRANK SHAFT**

REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
006	157-11666-90	1	
007	255-04200-20	1	
008	018-01805-20	1	
011	002-04215-20	1	-P224730
011	002-04240-20	1	P224731-
012	990-51050-183	4	
013	992-10050-062	4	
014	017-04230-20	1	
015	041-04050-20	2	
016	031-04200-20	1	
017	037-01000-20	1	
018	039-05004-20	2	
021	046-04200-80	1	
022	999-62101-004	1	
031	068-02000-20	1	

# B11-02


# SUM-500/500N CRANK CASE




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
023	991-11100-013	1	
024	798-05015-20	1	
026	072-04215-90	1	
027	090-04200-21	1	
028	999-66152-500	2	
029	999-61620-200	2	
030	070-02401-20	2	
032	071-02007-20	V	
032	071-02007-21	V	
032	071-02007-22	V	
032	071-02007-23	V	
032	071-02007-24	V	
036	990-11060-451	2	
037	992-10060-012	2	
038	990-11060-301	2	
039	992-10060-012	2	
051	155-20520-80	1	
052	992-00100-011	1	
054	991-11100-011	1	
055	167-20505-80	1	
056	990-11050-181	3	
057	992-10050-012	3	
058	992-00050-011	3	
059	159-20505-80	1	
060	990-11050-141	2	
061	992-10050-012	2	
062	992-01050-011	2	
063	198-05015-80	1	
066	112-04230-20	1	
067	994-14060-202	4	
068	203-10000-20	1	
069	203-06000-20	1	
070	178-04215-80	1	
071	274-04215-80	1	

# B11-03


# SUM-500/500N ENGINE



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	738-04230-20	1	
002	994-15050-122	1	
003	990-11050-121	1	
004	992-01050-011	1	
005	990-53060-653	2	
006	992-01060-011	2	
007	706-0421A-80	1	
009	708-01028-80	1	
010	990-11040-121	1	
011	991-01040-011	1	
014	737-04230-20	1	
016	133-0421A-20	1	
020	990-11060-302	2	
021	992-10060-042	2	
023	994-15050-252	2	
025	994-15050-162	2	
031	403-04230-20	1	
032	404-04215-20	1	
033	407-04215-20	1	
034	393-05004-20	1	
051	359-10112-20	2	
052	290-04200-80	2	
053	342-04200-20	1	
054	358-10112-20	2	
055	357-04201-20	2	

**B11-04****SUM-500/500N AIR CLEANER**


REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
000	410-00610-90	1	
001	423-00610-21	1	
002	446-00610-20	1	
003	436-00610-21	1	
004	990-11040-251	2	
005	992-10040-012	2	
006	992-00040-011	2	

**B11-05****SUM-500/500N RECOIL STARTER**

REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
000	762-05015-91	1	
001	815-06000-20	1	-Q073260
002	785-05004-20	1	
003	772-05015-80	1	
004	779-06000-20	1	
005	783-05004-20	1	
006	769-05015-20	1	
007	788-05015-20	1	-Q073260
007	788-05015-21	1	Q073261-
008	801-05015-20	1	
010	837-05015-20	1	-Q073260
010	837-05015-21	1	Q073261-
011	822-05015-20	1	-Q073260
011	822-05015-21	1	Q073261-
012	839-05015-20	1	

# B11-06


# SUM-500/500N CARBURETOR



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
000	455-21811-90	1	-P224730
000	455-21814-90	1	P224731-
001	560-20230-20	1	
002	597-20110-20	1	
003	991-01060-003	1	
004	595-20230-20	1	
005	594-20200-20	1	
006	619-20203-20	1	
007	592-2048T-92	1	
008	593-20400-20	1	
009	591-2025T-20	1	
010	622-20110-20	1	
011	623-21700-20	1	
013	561-20219-90	1	
014	571-20200-20	1	
015	994-14040-121	2	
016	603-21811-80	1	
017	607-20110-20	1	
018	605-21011-20	1	
019	628-20219-20	1	
020	598-2011T-85	1	
021	599-2001T-70	1	-P224730
021	599-2001T-66	1	P224731-
022	604-21014-20	1	
023	606-20433-80	1	
030	493-21810-00	1	
031	492-20447-20	1	
032	494-20447-20	1	
033	493-21810-20	1	
034	506-20447-20	1	
035	991-01060-003	1	


# B11-07

# SUM-500/500N FRAME



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	244-33392-81	1	P224731-
002	245-33360-80	1	
003	746-33331-90	1	
005	990-14050-121	2	
009	994-15050-122	2	
010	221-33390-80	1	
011	319-33390-80	3	
012	991-82060-001	6	
013	992-01080-011	1	
014	992-10080-012	1	
015	990-51080-143	1	
016	999-61600-201	1	
017	382-33360-21	1	
018	992-01050-011	3	
019	992-10050-012	3	
020	990-11050-121	3	
022	591-01047-20	1	
023	648-33328-20	2	
024	990-11050-221	2	
025	992-10050-012	2	
026	992-00050-011	2	
028	595-0130F-90	1	
029	626-32550-20	1	
030	222-31700-20	1	
031	680-10209-20	1	
032	592-10209-90	1	
033	680-01004-20	1	
034	700-15008-27	1	
035	702-33340-20	1	
042	220-33390-80	1	
043	992-10050-062	4	
044	990-51050-123	4	
047	345-33390-20	1	
048	992-10050-012	2	
049	990-11050-121	2	




**B11-08****SUM-500/500N CLUTCH CASE / FLEXIBLE SHAFT**

REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	332-33340-80	1	
002	993-51035-002	1	
003	999-61620-201	1	
004	993-50015-002	1	
006	331-33390-20	1	
007	992-10050-062	4	
008	990-51050-123	4	
009	400-33365-80	1	
010	164-10015-00	1	
016	164-10067-00	1	-P224730
016	164-10070-00	1	P224731-
017	198-33386-20	2	
020	351-33387-90	1	-P224730
020	351-3338F-90	1	P224731-
021	351-33387-80	1	-P224730
021	351-3338F-80	1	P224731-
022	350-33387-80	1	-P224730
022	350-33390-80	1	P224731-

**B11-09****SUM-500/500N OPERATION PIPE (SUM-500)**


(SERIAL NO. -P049420)



REF NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	504-37003-20	1	
002	281-33386-90	1	-P005185
002	281-33386-91	1	P005186-
003	990-51050-253	1	
004	990-51050-223	1	
005	992-10050-062	2	
006	356-33386-20	1	
007	999-61600-004	1	
009	342-33328-20	1	
011	990-51050-103	1	
026	500-33341-20	1	
027	506-33341-20	1	
028	990-23060-401	2	
029	992-01060-011	2	
031	991-01060-011	2	
032	341-33386-80	1	
033	347-33411-91	4	
035	343-33386-20	1	
036	708-32350-20	1	
037	887-3338A-80	1	
038	888-04030-20	1	
039	885-0136U-80	1	
041	178-33340-80	2	
047	990-72045-204	1	
050	285-33386-21	1	

**B11-10****SUM-500/500N THROTTLE LEVER (SUM-500)**

(SERIAL NO. -P049420)




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
060	870-33340-90	1	
061	880-37101-20	1	
062	832-37101-20	1	
063	162-37101-20	1	
064	262-37101-20	1	
065	176-37101-20	1	
066	177-37101-20	1	
067	259-37101-20	1	
068	993-42030-081	3	
069	315-33340-20	1	
070	993-55060-001	1	
071	994-31050-201	1	
072	853-37101-20	1	
073	958-37101-20	1	
074	956-37101-20	1	
075	260-33340-20	1	

# B11-11

# SUM-500/500N OPERATION PIPE (SUM-500N)


(SERIAL NO. P224731-)



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
016-1	500-33341-20	1	-Q019230
016	500-33560-20	1	Q019231-
021	991-01060-041	2	
022	341-3338F-80	1	
023	347-33411-91	4	
039	885-0136U-80	1	
040-2	506-33341-20	1	-Q019230
040-1	506-33560-20	1	-R274200
040	520-33398-20	1	Q019231-
043-1	990-23060-401	2	-Q019230
043	994-23060-432	2	Q019231-
044	992-01060-011	2	-Q019230
045	343-3338E-21	1	
046	708-32350-20	1	
048	888-04030-20	1	
053	990-51050-253	1	
055	992-10050-062	2	
057	990-72045-204	1	
058	281-33386-91	1	
059	990-51050-223	1	
077	342-33328-20	1	
078	999-61600-004	1	
079	356-33386-20	1	
080	285-33386-21	1	
081	990-51050-103	1	

**B11-12****SUM-500/500N THROTTLE LEVER (SUM-500N)**


(SERIAL NO. P224731-)



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
083	885-3338F-80	1	
085	870-3338F-90	1	
086	883-37411-90	1	
087	883-37411-20	1	
088	991-91060-061	2	
089	994-31060-203	2	
090	889-37411-90	1	
091	889-37411-20	1	
092	253-37411-20	1	
093	156-3338F-80	1	
096	875-37376-21	1	
097	884-37376-21	1	
098	832-37411-20	1	
099	880-37411-20	1	
100	956-37411-20	1	
101	958-37411-20	1	
105	993-42040-182	4	

# B11-13

# SUM-500/500N GEAR CASE / GUARD



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	300-37134-90	1	
002	990-51050-253	2	
003	992-10050-062	2	
004	993-51024-002	1	
005	993-50009-002	1	
006	999-61609-002	1	
007	999-61609-000	1	
009	300-3330B-20	1	
011	990-51050-103	1	
012	990-15080-100	1	
013	999-61628-000	1	
015	304-37380-20	1	-P219150
015	304-37134-20	1	P219151-
016	999-61620-103	1	
017	993-51032-002	1	
018	310-37623-20	1	
019	311-37300-20	1	
022	312-33386-20	1	
023	324-37350-20	1	
025	067-37134-20	1	P219151-
026	990-53060-153	2	
027	992-10060-062	2	
035	301-33395-00	1	-P219150
035	301-37134-00	1	P219151-
036	442-33671-20	1	
038	441-37003-80	1	
046	990-53060-253	2	
047	992-10060-062	2	
048	442-33699-20	1	
049	441-37380-20	1	
050	445-37380-20	1	
051	447-37380-20	1	
052	797-37380-21	1	
053	992-10050-012	1	
054	990-11050-121	1	
056	991-01050-011	1	
057	308-33410-20	1	
058	441-33625-90	1	