## Tanaka<sup>\*</sup>


# Parts Catalog

### Brushcutter

Model: TBC-262


All Units After Serial Number G 231370


#### FIG.1 ENGINE



REF NER PARTIER	PARTIANE	SERIA MER REMARKS
1-001 002-01601-800 1-002 018-00502-200 1-003 157-04000-900	CYLINDER COMP. SPARK PLUG BM6A SPARK PLUG CAP ASS'Y CYLINDER GASKET PISTON RING	1 1 1 1 2 1 1 1 2 1 1 1 1 2 1 1 1 1 1 2 1
1-009   046-01620-801 1-009   046-01620-800 1-010   999-62081-225	PISTON PIN PISTON PIN CIRCLIP CRANK SHAFT COMP. CRANK SHAFT COMP. NEEDLE BEARING F-810 WOOD-RUFF KEY 3X13X4.5	1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
1-012   071-02007-210 1-012   071-02007-220 1-012   071-02007-230 1-012   071-02007-240	CRANK SHAFT SHIM 0.05 CRANK SHAFT SHIM 0.10 CRANK SHAFT SHIM 0.15 CRANK SHAFT SHIM 0.20 CRANK SHAFT SHIM 0.30 BALL BEARING #6002. 32MM/OD	V V V V V V V V V V V V V V V V V V V
1-015   999-66152-500 1-016   999-66122-266 1-017   090-00601-205 1-018   072-01620-900	BALL BEARING #6001, 28MM/OD OIL SEAL 15257 OIL SEAL 12227 CRANK CASE GASKET CRANK CASE ASS'Y CLUTCH WASHER B	
1-021   155-21720-800 1-021   155-21720-801 1-021   155-21720-802	STARTER PULLEY MAGNETO ROTOR COMP. MAGNETO ROTOR COMP. MAGNETO ROTOR COMP. IGNITION COIL BRACKET IGNITION COIL BRACKET	1 R -D149567 1 R -E073890 E073891- 1 1 -F141220 1 F141221-
1-023   167-21507-802 1-024   904-01620-200 1-024   904-01620-201 1-025   894-01401-201	IGNITION COIL COMP. IGNITION COIL COMP ADJUSTER BRACKET ADJUSTER BRACKET OUTER RECEIVER IGNITOR COMP. TTI-1F	1
1-028   255-0608A-200 1-030   990-11050-161 1-031   992-10050-012 1-032   991-01080-011	S. WASHER 5	1 N D170956-
1-035 1-036 991-01080-011 1-041 991-01060-013 1-042 990-11050-301 1-044 990-11050-161	HEX. NUT 8 NUT 6 SCREW 5X30 S.WASHER 5	1 1 1 4 4 4 2
1-045 1-046 1-047 1-047 1-048 1-049 1-050 1-050 1-050 1-049 1-050	SCREW 4X18 S.WASHER 4 SMALL WASHER 4 SCREW 4X8	2 2 2 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
1-051 1-052 992-10050-012	I	

#### FIG.2 ENGINE COMPONENTS






REF NBP PARTER	PARMANE	SERIA NER PENARAS
2-001 738-01620-200 2-001 738-01620-201 2-002 257-0630B-201 2-002 257-0630B-210 2-003 203-0630B-200	NUFFLER PROTECTOR HUFFLER PROTECTOR SPARK PLUG COVER SPARK PLUG COVER PRIMARY CORD GROWNET PRIMARY CORD GROWNET	1 R -D149567 D149568- 1 -D074939 1 P D074940- 1 -D074939 1 P D074940-
2-005   653-01620-200 2-007   655-06100-200 2-008   359-02103-200 2-009   290-01620-800	CYLINDER COVER COLLAR TANK BRACKET FUEL TANK CUSHION RUBBER CLUTCH WASHER B CLUTCH SHOE COMP. CLUTCH SPRING	1 1 4 2 2 2 1
2-014   289-01620-800 2-015   993-51032-002		2 2 1 1 1 1 1 2 1 1 2 1 1 2 1 1 1 2 1 1 1 1 2 1 1 1 1 2 1 1 1 1 2 1
2-018 2-019 2-020 2-020 198-01046-900 2-020 198-05015-800	STOP RING C-15 EX FAN CASE CLUTCH CASE CORD CLAMP ASS'Y CORD CLAMP COMP. ANTI-VIBE CASE A	1
2-022   599-01620-200 2-023   176-01620-200 2-024   539-01620-200	ANTI-VIBE CASE A CUSHION RUBBER EARTH TERHINAL ANTI-VIBE CASE B ANTI-VIBE CASE B HEAT SHIELD	F001501-  R -F001500 F001501-
2-027, 1 705-01620-902	HEAT SHIELD HEAT SHIELD NUFFLER GASKET	-D149567 1 M 1 N D149568- 1 N D149568- -D149567 D149568-
2-029, 1 717-01620-800 2-029 717-01620-810	MUFFLER COUPLING GASKET MUFFLER BODY B COMP. MUFFLER BODY B COMP. CUSHION RUBBER	1
2-034   404-01620-801 2-035   402-00601-202 2-036   700-03005-150	INLET MANIFOLD GASKET CARBURETOR INSULATOR COMP. CARBURETOR GASKET FUEL PIPE 3X5X150 RUBBER PIPE CAP RUBBER PIPE	
2-041   680-04019-210 2-041   680-00731-201 2-042   595-0062A-910	CLIP TANK CAP ASS Y, ORANGE TANK CAP ASS Y	
2-053	FUEL TANK STAND CUSHION RUBBER	1 R -D149567 1 D149568- 1 N E306501- 1 N E306501- 2 -E306500
2-057, 1 990-11040-161 2-057 994-15040-162 2-058 992-10040-012	SCREW 4X16/PS	2 M 2 N E306501- 2 D E306501-


<u>a</u>	<del>,                                    </del>			/ .6
REF. HER	PARMER	PARTIANE	SERIAN SERIAN SER	REMARKS
2-059   992-010   2-060,1   990-110		2	2 D E306501-	<i>Y</i>
2-062 2-063.1 990-110 2-063 994-150 992-100	050-012   S.WASHER 5 050-011   WASHER 5 050-121   SCREW 5X12 050-122   SCREW 5X12/ 050-012   S.WASHER 5 050-011   WASHER 5	PS 3 3 3 3 3	1 M 3 H 3 N	
2-068   990-316 2-068   990-336 2-069   990-216 2-069   990-216	060-012 060-181 060-181 060-181 060-251 060-251 060-221 060-221 060-221 060-221	/PLUS 2	4 H 4 2 4 2 4 2 4 2 4 2 4 2 4 2 4 2 4 2	
2-071 990-110 2-072 992-100 2-073 992-000 2-074 992-100	060-012 S.WASHER 6 050-121 SCREW 5X12 050-012 S.WASHER 5 050-011 SWALL WASHE 050-012 S.WASHER 5 050-601 SCREW 5X60	2 1 1 1 2 2 2 2 2 2 2	1 N G065502- 2 2	
2-076 2-077,1 990-230 2-077,2 990-110 994-130	050-011 HEX. NUT 5 050-010 U-NUT 5 050-156 BOLT 5X15 040-121 SCREW 4X12 040-122 SCREW 4X12/ 050-012 S. WASHER 5	2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	2	
2-078.2 200-010 2-078 992-010 2-079.1 994-140 2-079 990-510	620-200 LOCK WASHER 620-200 LOCK WASHER 040-011 WASHER 4 060-152 SCREW 6X15/ 050-453 HEX. HOLE B 060-061 WASHER 6	2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	2 D D149568- 2 M 2 2 -D149567 2 N D149568-	
2-081.1 990-110 2-081 994-150 2-082 992-100 2-083 992-010	050-061 WASHER 5 040-141 SCREW 4X14 040-142 SCREW 4X14/ 040-012 S.WASHER 4 040-011 WASHER 4 050-161 SCREW 5X16	PS 22 2 2 2 4	2 N D149568- 2 N 2 N 2 N 2 N 2 N 3 N 3 N 3 N 3 N 3 N	
2-086 990-110 2-087 992-100 2-088 992-000 2-089 990-110	050-012 050-221 050-221 050-012 050-012 050-011 050-101 050-011 050-011 VASHER 5	R 5	2	

#### FIG.3 AIR CLEANER




	NER PARMER PARMANE	SERIA NER REMARKS
3-000	410-0602D-900 AIR CLEANER ASS'Y	1 R -D114148
3-000	410-0602D-901 AIR CLEANER ASS'Y 424-0602K-200 AIR CLEANER CAP	1
3-001	424-0602K-201 AIR CLEANER CAP	1 D114149-
3-002	446-0602K-200 CLEANER ELEMENT	11
3-003	453-0602K-200   SPACER	
3-004	470-0602K-200 COLLAR	
3-005	528-0602D-200 CHOKE PLATE. W/2HM HOLE	
3-006	423-0602K-200 CLEANER BODY	i
3-006	423-0602K-210 CLEANER BODY	1 N D114149-

#### FIG.4 RECOIL STARTER




REF	WER PARWER	PARTNAME	SERIANDER REMARKS	,
4-000	762-01620-900	RECOIL STARTER BODY ASS'Y	1	
4-001		RECOIL STARTER BODY STARTER ROPE REEL		- 1
4-002	788-01250-200			
4-004		RECOIL SPRING		
4-005		FRICTION SPRING	i w	1
1				
4-005	836-06092-200	FRICTION SPRING		i
4-006		FRICTION PLATE	1   N	
4-006		FRICTION PLATE		
4-007		RETURN SPRING		- 1
4-008	990-15050-121			
4-009	783-06092-200	ROPE 3.5X890L	1	
4-009	797-06150-200	ROPE 3.5X890L		1
4-009	783-06150-200 783-0162V-200			l
4-010		STARTER HANDLE		i
4-011	780-06150-200			
4-012		HANDLE KNOB SEAL		


#### FIG.5 CARBURETOR



		<u> </u>	
REF	NER PARTIER	CARBURETOR ASS: Y WA-164	SERIA NER REMARKS
5-000 5-001 5-002 5-003 5-004 5-005	455-25023-900 575-25010-200 577-25007-200 576-25006-200 475-25001-200	PUNP BODY	
5-006 5-006 5-007 5-008 5-008 5-009	476-25004-200 464-25010-800 486-25006-200 486-25009-200	DIAPHRAGN COVER DIAPHRAGN COVER THROTTLE SHAFT COMP. THROTTLE SPRING THROTTLE SPRING THROTTLE VALVE	
5-009 5-010 5-011 5-012 5-013 5-014	557-25006-200 460-25023-200 485-25003-200 461-25023-200	THROTTLE VALVE THROTTLE SHAFT CLIP HIGH ADJUST SCREW LOW ADJUST SCREW HIGH/ŁOW ADJUST SPRING	
5-015 5-016 5-017 5-018 5-019 5-020	462-25006-200	IDLE ADJUST SCREW IDLE ADJUST SPRING VALVE SPRING NEEDLE VALVE VALVE HINGE	
5-021 5-021 5-022 5-022 5-023 5-023	578-25006-200 578-25007-200 539-25006-200 539-25008-200 489-25006-200 489-25008-200	INLET SCREEN INLET SCREEN SVIVEL SVIVEL STOP RING	
5-024 5-024 5-025 5-026 5-027	548-25014-200 548-25012-200 514-25001-200 546-25001-200	SET SCREW	1


#### FIG.6 HANDLE






REF	NER PARNER	PARTHAME	SERIA NER	REMARKS
6-001 6-002 6-003 6-004 6-005 6-006	500-33560-200 343-37000-200 341-33560-801 347-33411-912 506-33560-200			
6-007 6-008 6-010 6-011,1 6-011,1	748-33564-900 504-33412-200 870-0062M-900 870-00741-900		H E244276- H -D149567 -E244275	į
6-011 6-012 6-013 6-014 6-015 6-016	178-37003-800 183-01300-200 640-33905-200 883-33564-800	THROTTLE LEVER ASS'Y STOP CORD COMP. SWITCH NAME PLATE STOP BUTTON BRACKET THROTTLE LEVER BAND COMP. STOP SWITCH ASS'Y	P E244276- N D149568- D D149568- D D149568- D D149568- D D149568-	
6-017 6-018 6-019 6-020 6-021 6-022	990-11050-141 168-33905-201 178-0162R-800 991-01060-011 990-21060-451 991-01050-011	STOP BUTTON COVER STOP CORD COMP. NUT 6 BOLT 6X45	D D149568- D D149568- D D149568-	
6-023 6-024 6-025 6-026 6-041 6-042	992-10060-012 992-01060-011 992-10050-012 990-11050-161 880-33564-200 832-33564-200	WASHER 6 S.WASHER 5 SCREW 5X16	N D149568- N D149568-	
6-043 6-043 6-043 6-044 6-045 8-046	176-33564-200	STOP SWITCH	N D149568~ -E244275 N E244276- N D149568- N D149568- N D149568-	:
6-047 6-048 6-049 8-049 6-049	I .	SCREW 5X30 SCREW 5X30	N D149568- N D149568- D149568- -F141220 P F141221- N D149568-	
6-051		SELF-LOCK NUT 5	N D149568-	
	,			
				:

FIG.7 GEAR CASE




	- A	<del></del>	777 7 5
REF	NEP PARNER	PARMANE	STY SERVANDER REMARKS
7-001,1 7-001 7-001 7-001 7-001 7-003,1	300-37000-900 300-37000-910 300-37000-910 300-37000-911 300-37000-912	GEAR CASE ASS'Y	-D149567 1 N -E244275 1 R -E244275 1 R -G230370 1 G230371- 1 -D149567
7-003 7-003 7-003 7-003 7-004 7-005	300-33410-210 300-33410-210 300-33410-211 300-33410-212 302-37000-200 301-33411-200	GEAR CASE GEAR CASE GEAR CASE PINION	1 N -E244275 1 R -E244275 1 R -G230370 1 G230371-
7-006 7-007 7-008 7-008 7-009 7-009	999-61600-004 999-61600-003 999-61600-204	BALL BEARING #6000. 26MM/OD BALL BEARING #6000DD, 26MM/OD BALL BEARING 6000D. 26MM/OD BALL BEARING #6002DD. 32MM/OD	1
7-010 7-011 7-012 7-013 7-014 7-015	993-50010-002 993-51026-002 324-33410-201 990-51050-203	STOP RING C-26 IN GEAR CASE WASHER HEX. HOLE BOLT 5X20	1 1 1 1 2 2 2 2
7-016 7-017 7-020.1 7-020 7-020 7-020	310-33410-202 310-33524-201 310-33524-201	OILING GASKET CUTTER HOLDER CUTTER HOLDER CUTTER HOLDER	2   - D149567   - G230370   - G230371 -   G230371 -   C230371 -   C330371 -     C330371 -   C330371 -   C330371 -     C330371 -     C330371 -     C330371 -     C330371 -     C330371 -     C330371 -       C330371 -
7-021 7-022 7-023 7-024 7-029 7-030	992-29080-000 312-33411-200 992-01080-011 445-33578-200	TOOTHED LOCK WASHER 8 L/H CUTTER FIXING BOLT/L.H.T. WASHER 8 SAFETY GUARD HOLDER	1
7-030 7-031,1 7-031 7-031 7-031 7-032	441-33671-200 441-37003-800 441-37003-800 441-37003-801	SAFETY GUARD SAFETY GUARD COMP., METAL SAFETY GUARD COMP., METAL SAFETY GUARD COMP., METAL	D149568- -D149568- -D149568- 1 R = 2444275 E244276-
7-033 7-035 7-037 7-038 7-040 7-041	992-10060-012 990-11050-181 992-01050-011 992-10050-012 800-33005-201 990-11040-121	SCREW 5X16 WASHER 5 S.WASHER 5 CORD CUTTER BLADE	2
7-042 7-043	992-01040-011 799-33005-200	WASHER 4 BLADE GUIDE	2 D D149568- 1 D D149568-

#### FIG.8 TOOLS & NYLON HEAD



/	aR		/// / 6
REF	NER PARTIER	THYLON HEAD ASS'Y (TH-05Y)	SE RIMINER REMARKS
8-000 8-001 8-002 8-003 8-005 8-006	783-33440-901 786-33004-801 789-33004-201 787-33004-202	CUTTING BODY COMP. BODY CAP CORD REEL 8X1.25 L/H BOLT (GOLD)	
8-007 8-008 8-009 8-010 8-011 8-021	673-35600-200   793-33440-200   358-02103-200	REEL SLIDER HOOK STEEL BALL 5/16" REEL SPRING (GOLD)	1 1 4 1 1 1 D D149568-
8-022,1 8-022 8-023 8-024 8-025 8-026	752-33900-200 813-20000-200 826-20000-200 951-20000-200	HEX. WRENCH 4 BOX SPANNER 17X19	1 1 N -D149567 D149568-
8-027 8-028 8-030 8-032 8-033 8-034	801-20000-200 316-33410-200 540-33671-900 615-33411-900 615-33411-200	SPANNER 8X10 BOLT PROTECTION COVER GOGGLE ASS'Y CUTTER COVER ASS'Y	
8-035 8-035	948-32310-200 948-39907-200	TOOL BAG	1   1   -G005000 G006001-

#### FIG.9 MARKS



D

E244276~

9-003

9-004 9-005