HITACHI

LIST NO. 0889

ELECTRIC TOOL PARTS LIST

■ CHARGER

1985·5·10

Model UC7Y

UC7Y(E1)



PARTS

UC7Y(E1)

Item No.	Code No.	Part Name	Q'ty	Remarks	
1	—	Rivet	2	See alternative parts	
2	—	Name Plate	1		
3	—	Case	1	See alternative parts	
4	980623	Cushion	2		
5	993969	Printed Circuit Board Ass'y	1	includ. 20	
6	993972	Fin	1		
7	993963	Machine Screw M3 x 12	1	W/Spring Lock Washer, Bolt Washer	
8	984404	Cushion	1		
9	956636	Tapping Screw D4 x 25	4	W/Washer	
10	—	Fuse	1	See alternative parts	
11	—	Plug	1	See alternative parts	
12	993964	Tube (A)	1		
13	—	Cord Armor	1	See alternative parts	
14	937631	Cord Clip	1		
15	930446	Tapping Screw D4 x 16	2	W/Washer	
16	993965	Internal Wire (Red)	1		
17	993966	Internal Wire (Black)	1		
18	993967	Internal Wire (White)	1		
19	—	Vinyl Tube (I.D6 x T0.5 x 10)	1		
20	993962	Thermostat	1		
21	993968	Spacer	1		

ALTERNATIVE PARTS

Item No.	Code No.	Part Name	Q'ty	Remarks	
1	949510Z	Rivet D2.5 x 4.8	2	for U.S.A., Canada (10 pcs.)	
3	980630	Case	1		
	980646Z	Case	1	for U.S.A., Canada	
	980615Z	Case	1	for Australia, Finland	
	993973	Case	1	for Italy	
10	993960	Fuse	1		
	993961	Fuse	1	for U.S.A., Canada	
11	993970	Plug	1		
	993971	Plug	1	for U.S.A., Canada	
13	991167	Cord Armor	1		
	991168	Cord Armor (B)	1	for U.S.A., Canada	